

# Satellite Current Monitoring (DM) Connectivity Diagram

## Satellite Current Monitoring



Connect to: RSMINI,  
RSE, RSO, RCX, RSM,  
RCM or RCU